


CRANK SCRAPER & WINDAGE TRAY FOR LS & VORTEC ENGINES

3.622" STROKE & 4.000" STROKE ENGINES

MADE IN USA



Important: Read these instructions in their entirety prior to installation

For contact information, visit www.improvedracing.com Copyright © 2008-2020 Improved Racing Products, LLC. All rights reserved.

APPLICATIONS

 Ensure you have purchased the correct crankshaft scraper kit for your application. Refer to http://www.improvedracing.com/tech/crank-scraper-applicationlist.php for a list of supported vehicles by specific part number.

GENERAL PARTS LIST





Figure 1 - EGM-7XX Schematic

Item	Qty	Part Number	Description
1	1	EGM-3XX	Crankshaft Scraper (Part Number Engraved on Scraper)
2	1	EGM-240X	Windage Tray (Long & Short Versions)
3	4	HSP-1009	M10 ARP Stud to M8 Factory Stud Reducer
4	10	HNT-1018	M8x1.25 (Factory Stud) Crank Scraper Locknuts
5	4-7	HSC-1037	M6x1.00 Windage Tray Screws

TECHNICAL SPECIFICATIONS

Ideal Scraper Clearance	ALL SCRAPING SECTIONS: 0.040 inches (1.02 mm)
Minimum Scraper Clearance	ALL SCRAPING SECTIONS: 0.020 inches (0.51 mm)
EGM-3XX Info	CNC-Machined 6061-T6 Billet Aluminum
EGM-240X Info	CNC-Pierced 5052-H32 Sheet Aluminum, Jig-Bend with Press
HSP-1009 Info	CNC-Machined 6061-T6 Billet Aluminum
HNT-1018 Info	IFI-100/107 M8x1.25 Class 10 Top Locknut, C10B21 Alloy Steel, CR3+ Zinc Plated, 6H Thread Fit, 13 mm Wrench Flats
HSC-1037 Info	M6x1.00x12 ISO 7380 Low-Profile Button Head Screw, 304 Stainless Steel, 6g Thread Fit, 4 mm Drive

WARNINGS & PRECAUTIONARY STATEMENTS



WARNING: This product should only be installed by a qualified mechanic. Improper installation could result in severe engine damage.

REMOVING THE FACTORY PARTS

- 1. Raise and support the vehicle at the recommended lift points using a lift, jack stands or wheel ramps.
- \(\text{Lift points are found in the vehicle owners manual.} \)
- 2. Remove any fascia panels required to access the vehicle's oil filter and oil pan / oil reservoir.
- 3. Drain the oil reservoir (dry-sump) or the oil pan (wet-sump) by following GM's approved method for your vehicle, found in the service manual.
- **⚠** Caution: Oil may be hot!
- 4. Place a drain pan underneath the oil filter and remove the filter.
- 5. Remove the oil pan from the vehicle by following GM's approved method for your vehicle, found in the service manual.
- 6. Wet-sump vehicles must remove the factory oil pickup tube (screen) from the oil pump and main stud(s) by using a 10 mm and 13 mm tool, shown in Figure 2. Set the pickup tube (screen) aside until reinstallation.
- **Tip:** Nut(s) and screw locations vary among vehicles.




Figure 2 - Removing the Factory Oil Pickup Tube (Screen)

- 7. Use a 13 mm tool to completely remove the factory windage tray. This is illustrated in Figure 3.
- **Tip:** Some vehicles only have eight nuts total.
- **Tip:** The factory windage tray will not be used again.




Figure 3 - Removing the Factory Windage Tray

8. If your oil pan is equipped with one, remove the shroud from the oil pan pressure relief valve, shown in Figure 4.




Figure 4 - Pressure Relief Valve Shroud to Remove

INSTALLING THE IMPROVED RACING KIT

- 1. Clean the crankshaft scraper and windage tray thoroughly using a mild detergent and warm water.
- 2. Dry both parts with compressed air and / or a lint-free towel.
- 3. If installing an ARP stud kit, follow the instructions provided with the kit before proceeding with the crank scraper installation.
- 4. If using the factory main cap hardware, insert the four HSP-1009 reducer bushings as shown in Figure 5 while securing the scraper to the engine.




Figure 5 - Inserting the Reducer Bushings for Factory Main Studs

- 5. Use Figure 6 to ensure the scraper is oriented correctly, then loosely secure the scraper to the main caps.
 - a. Use a 13 mm tool for the provided HNT-1018 nuts.
 - b. Use a 14 mm tool for the ARP flange nuts provided in the stud kit.






Figure 6 - Correct Crank Scraper Orientation

- 6. Using a $\frac{1}{2}$ inch-drive breaker bar or ratchet with a 24 mm ($\frac{15}{16}$ inch) socket, manually turn the engine in the clockwise direction while carefully inspecting clearance / interference. This is shown in Figure 7.
- **Tip:** To make this step easier, place the transmission into neutral and loosen the spark plugs to relieve combustion chamber pressure.




Figure 7 - Rotating the Engine Crankshaft with a Breaker Bar

- 7. Use a feeler gauge set, shown in Figure 8, to carefully measure the gap between the scraper and the rotating assembly in-as-many positions as possible. Please be thorough!
- **Ensure the gap is AT LEAST 0.020" in every location.**
- ⚠ If interference is detected, loosen the scraper and adjust the fit until all clearances are AT LEAST 0.020".
- **Tip:** In rare instances, the scraper will require minimal filing to achieve the required clearances. Unsure? Contact <u>Customer Service</u>.




Figure 8 - Inspecting Clearance with a Feeler Gauge

- 8. Torque the crank scraper nuts (HNT-1018 or ARP) to 18 lb-ft (24 N·m).
- **Tip:** Do not install the nut(s) that secure the oil pickup tube (screen) yet.
- 9. Secure the Improved Racing windage tray to the crank scraper using all of the HSC-1037 screws provided with the kit, as shown in Figure 9. Use a 4 mm hex tool to torque the screws to 5 lb-ft (6 N·m).




Figure 9 - Installing the Improved Racing Windage Tray

10. If using ARP main studs, enlarge the pickup tube (screen) mounting hole(s) with a $\frac{7}{16}$ inch (11 mm) drill bit. The hole(s) is shown in Figure 10.




Figure 10 - Hole(s) to Enlarge on the Pickup Tube (Screen)

- 11. Re-install the oil pickup tube (screen).
- **Tip:** Replace the oil pickup tube (screen) O-ring with a new O-ring. This is recommended for higher mileage engines.
- 12. Use a 10 mm tool to torque the pickup tube flange screw on the engine oil pump to 8 lb-ft (10 N·m).
- 13. Use a 13 mm tool to torque the remaining oil pickup tube nut(s) to 18 lb-ft (24 N·m).
- 14. Perform a final inspection of the crank scraper and windage tray. Rotate the engine manually using the breaker bar and check for interference again. Return to Step 5 and readjust when necessary.
- 15. Retighten the spark plugs.
- 16. Reinstall the vehicle's oil pan by following GM's approved method for your vehicle, found in the factory service manual.
- ♠ Ensure that the crank scraper and windage tray DO NOT interfere with the oil pan.
- **Tip:** Replace the oil pan gasket with a new gasket. This is recommended for higher mileage engines.
- 17. Pre-fill and reinstall a new engine oil filter after lubricating the seal with engine oil.
- 18. Refill the engine oil to the factory specifications.

Congratulations! The installation of your crank scraper and windage tray is complete. Enjoy the additional horsepower and oil control!